

# **Current Transducer IN 1000-S**



For the electronic measurement of current: DC, AC, pulsed..., with galvanic separation between the primary and the secondary circuit.

# CE AR R⊠HS



#### Features

- Closed loop (compensated) current transducer using an extremely accurate zero flux detector
- 9-pin D-Sub male secondary connector
- Status signal to indicate the transducer state
- LED indicator confirms normal operation
- Metal housing to improve immunity to EMC & power dissipation
- Operating temperature -40 °C to 85 °C.

#### **Advantages**

- Very high accuracy
- Excellent linearity
- Extremely low temperature drift
- Wide frequency bandwidth
- High immunity to external fields
- No insertion losses
- Very low noise on output signal
- Low noise feedback to primary conductor.

#### **Applications**

- Feedback element in high performance gradient amplifiers for MRI
- Feedback element in high-precision, high-stability power supplies
- Calibration unit
- Energy measurement
- Medical equipment.

#### **Standards**

- EN 61000-6-2: 2005
- EN 61000-6-3: 2007
- EN 61010-1: 2010.

#### **Application Domain**

- Industrial
- Laboratory
- Medical.

#### 深圳市宇捷弘业科技有限公司



宇捷弘业公众号



电话: 400 186 5117 | 0755-2222 5117 | 137 5117 6688
Q Q: 138235948
微信: 13751176688
邮箱: info@itest.net
网址: www.itest.net
地址: 深圳市龙华区民治优城商务大厦北区A座921



## **Insulation coordination**

Parameter	Symbol	Unit	Value	Comment
RMS voltage for AC insulation test, 50 Hz, 1 min	$U_{d}$	kV	4.2	Between primary and secondary + shield
Impulse withstand voltage 1.2/50 µs	$U_{ m Ni}$	kV	8	
Clearance (pri sec.)	d <sub>ci</sub>	mm	11.5	Shortest distance through air
Creepage distance (pri sec.)	$d_{\rm Cp}$	mm	11.9	Shortest path along device body
Comparative tracking index	CTI		600	
Rated insulation RMS voltage	I	v	1000	Basic insulation according to IEC 61010-1 CAT III, PD2
Rated insulation RMS voltage	$U_{ m Nm}$	v	1000	Reinforced insulation according to IEC 61010-1 CAT II, PD2

# **Environmental and mechanical characteristics**

Parameter	Symbol	Unit	Min	Тур	Мах	Comment
Ambient operating temperature	T <sub>A</sub>	°C	-40		85	
Ambient storage temperature	Ts	°C	-40		85	
Relative humidity	RH	%	20		80	
Dimensions						See drawing on page 9
Mass	т	kg		1.3		

深圳市宇捷弘业科技有限公司

∎:i





П



#### **Electrical data**

At  $T_A = 25 \text{ °C}, \pm U_C = \pm 15 \text{ V DC}$ , unless otherwise noted. Lines with a \* in the comment column apply over the -40 ... 85 °C ambient temperature range.

Parameter	Symbol	Unit	Min	Тур	Max		Comment	
Primary continuous DC current (continuous)	I <sub>pndc</sub>	A	-1000		1000	*		
Primary nominal AC RMS current (continuous)	I <sub>pnac</sub>	А	-1000		1000	*		
Peak primary current, measuring range	$\hat{I}_{PM}$	A	-1500		1500	*		
Measuring resistance	R <sub>M</sub>	Ω	0		1		See graph on page 5 for other values	
Secondary nominal RMS current	I <sub>s n</sub>	A	-0.666		0.666	*		
Number of secondary turns	Ns			1500				
Resistance of secondary winding	R <sub>s</sub>	Ω		8	ĺ			
Maximum withstand primary peak current <sup>1)</sup>	$\hat{I}_{\rm P}$	kA	-5		5		@ pulse of 100 ms	
	$+U_{c}$	V	14.25	15	15.75			
Supply voltage DC	- <i>U</i> <sub>c</sub>		-14.25	-15	-15.75			
Current consumption positive DC	+I <sub>C</sub>	A		0.12			@ I <sub>p</sub> = 0	
					1.12			
	,	А		0.07	ĺ		@ I <sub>p</sub> = 0	
Current consumption positive DC	- <i>I</i> <sub>c</sub>				1.07			
RMS noise current 0 10 Hz 2)				0.05	0.1			
RMS noise current 0 10 kHz 2)	I <sub>no</sub>	ppm		1.5	4			
RMS noise current 0 160 kHz 2)				3.5	10			
Output peak-to-peak noise current <sup>2)</sup>	I <sub>no pp</sub>	ppm		18	34			
Electrical offset current + self magnetization + effect of earth magnetic field <sup>2)</sup>	I <sub>oe</sub>	ppm	-10		10	*		
Temperature coefficient of $I_{OE} \otimes I_{P} = 0 \text{ A}$	TCI <sub>OE</sub>	ppm/K	-0.3		0.3			
Linearity error <sup>2)</sup>	ε <sub>L</sub>	ppm	-2	1	2			
			-3	1	3	*		
Delay time to 90 % of $I_{PNDC}$	t <sub>D 90</sub>	μs			1		d <i>i</i> /d <i>t</i> of 100 A/µs	
Frequency bandwidth (±1 dB)	BW	kHz		230			Small-signal bandwidth, 1.5 % of I <sub>P N</sub>	
Frequency bandwidth (±3 dB)	BW	kHz		440				
Start-up time	t <sub>start</sub>	s			15			

Notes: <sup>1)</sup> Single pulse only, not AC. The transducer may require a few seconds to return to normal operation when autoreset system is running

<sup>2)</sup> All ppm figures refer to full-scale which corresponds to a secondary nominal RMS current.

深圳市宇捷弘业科技有限公司

П П 

宇捷弘业公众号



电话: 400 186 5117 | 0755-2222 5117 | 137 5117 6688

- Q Q: 138235948
- 微信: 13751176688 邮箱: info@itest.net
- 网址: www.itest.net



## **Overload protection - Electrical specification - Status**

The overload occurs when the primary current  $I_{\rm p}$  exceeds a trip level such that the fluxgate detector becomes completely saturated and, consequently, the transducer will switch from normal operation to overload mode.

This trip level is guaranteed to be greater than I<sub>PM</sub> and its actual value depends on operating conditions such as temperature and measuring resistance.

When this happens, the transducer will automatically begin to sweep in order to lock on the primary current again.

The overload conditions will be:

- The secondary current I<sub>s</sub> generated is a low frequency signal.
- The signal normal operation status (between pin 3 and 8 of the D-sub connector) switches to V+ or  $\approx$  0.7 V. See the status port wiring below.
- The green LED indicator (normal operation status) turns off. •

The measuring can resume when the primary current returns in the measuring range between  $-I_{PN}$  and  $+I_{PN}$ . Then the signal normal operation status switches to GND and the green LED indicator (normal operation status) switches on.

#### Status/Interlock port wiring



TRANSDUCER USER SIDE ı

The following table shows how the normal operation status acts as below:

Status	Value	Description
Active Low	≈ 0.7 V	The transducer is OK (Normal operation)
ACTIVE LOW	V+	The transducer is not OK (Overload mode or supply fault)
Active High	V+	The transducer is OK (Normal operation)
Active High	≈ 0.7 V	The transducer is not OK (Overload mode or supply fault)

#### 深圳市宇捷弘业科技有限公司





电话: 400 186 5117 | 0755-2222 5117 | 137 5117 6688

- Q Q: 138235948
- 微信: 13751176688

 $R_{\max}$  (k $\Omega$ ) =

2 mA

- 邮箱: info@itest.net
- 网址: www.itest.net
- 地址:深圳市龙华区民治优城商务大厦北区A座921

宇捷弘业公众号



#### Maximum measuring resistance versus primary current and temperature

 $\pm U_{c} = \pm 14.25 \text{ V}$ 





深圳市宇捷弘业科技有限公司



电话: 400 186 5117 | 0755-2222 5117 | 137 5117 6688

- Q Q: 138235948
- 微信: 13751176688 邮箱: info@itest.net

邮箱: Info@itest.net 网址: www.itest.net



#### Power supply and load

In order to reach the measuring range according to the maximum measuring resistor, be careful with the setup measurement when wires length are high. It means that:

- the wires resistance could be not negligible
- the voltage at the output of the DC power supply and the voltage at the transducer could be significantly different.



- S: Cross section of wire in m<sup>2</sup>
- l: Wire length in m
- $\rho$ : Resistivity of material in  $\Omega$ .m

#### Total measuring resistance is:

 $R_{\rm M} = R_{\rm L} + 2 \times R_{\rm W1} + 2 \times R_{\rm W2}$ 

If  $R_{W1} = R_{W2} = R_{WIRE}$  then  $R_M = R_L + 4 \times R_{WIRE}$ 

深圳市宁捷弘业科技有限公司



捷弘业公众号



电话: 400 186 5117 | 0755-2222 5117 | 137 5117 6688 Q Q: 138235948 微信: 13751176688 邮箱: info@itest.net 网址: www.itest.net

字捷弘业 深圳市宇捷弘业科技有限公司 itest.net

# Performance parameters definition

The schematic used to measure all electrical parameters is shown below:



#### **Transducer simplified model**

The static model of the transducer at temperature  $T_A$  is:

$$I_{\rm S} = N_{\rm P}/N_{\rm S} \cdot I_{\rm P} + \varepsilon$$

In which

$$\varepsilon = I_{OF}$$
 at 25 °C +  $I_{OT}(T_{A}) + \varepsilon_{I} \cdot I_{PM} \cdot N_{P}/N_{S}$ 

Where,

$$\begin{split} I_{OT}(T_{A}) &= TCI_{OE} \cdot |T_{A} - 25 \ ^{\circ}\text{C}| \cdot I_{PM} \cdot N_{P}/N_{S} \\ I_{S} & : \text{ secondary current (A)} \\ N_{P}/N_{S} & : \text{ turns ratio (1: } N_{S}) \\ I_{P} & : \text{ primary current (A)} \\ I_{PM} & : \text{ primary current, measuring range (A)} \\ T_{A} & : \text{ ambient operating temperature (}^{\circ}\text{C}\text{)} \\ I_{OE} & : \text{ electrical offset current (A)} \\ I_{OT} & : \text{ temperature variation of } I_{OE} \text{ at } T_{A}(A) \\ \varepsilon_{L} & : \text{ linearity error} \end{split}$$

This is the absolute maximum error. As all errors are independent, a more realistic way to calculate the error would be to use the following formula:

$$\varepsilon = \sqrt{\sum_{i=1}^{N} \varepsilon_i^2}$$

#### Linearity

To measure linearity, the primary current (DC) is cycled from 0 to  $I_{\rm P\,M'}$  then to  $-I_{\rm P\,M}$  and back to 0. The linearity error  $\varepsilon_{\rm L}$  is the maximum positive or negative difference between the measured points and the linear regression line, expressed in parts per million (ppm) of full-scale which corresponds to the maximum measured value.

#### **Electrical offset**

The electrical offset current  $I_{\rm O\ E}$  is the residual output current when the input current is zero.

The temperature variation  $I_{O\ T}$  of the electrical offset current  $I_{O\ E}$  is the variation of the electrical offset from 25 °C to the considered temperature.

#### **Delay times**

The delay time  $t_{D10}$  @ 10 % and the delay time  $t_{D90}$  @ 90 % with respect to the primary are shown in the next figure. Both slightly depend on the primary current di/dt. They are measured at nominal current.



深圳市宇捷弘业科技有限公司



电话: 400 186 5117 | 0755-2222 5117 | 137 5117 6688 Q Q: 138235948 微信: 13751176688 邮箱: info@itest.net 网址: www.itest.net



#### Safety

This transducer must be used in limited-energy secondary circuits according to IEC 61010-1.



This transducer must be used in electric/electronic equipment with respect to applicable standards and safety requirements in accordance with the manufacturer's operating instructions.



Caution, risk of electrical shock

When operating the transducer, certain parts of the module can carry hazardous voltage (e.g. primary busbar, power supply). Ignoring this warning can lead to injury and/or cause serious damage.

This transducer is a build-in device, whose conducting parts must be inaccessible after installation.

A protective housing or additional shield could be used. Main supply must be able to be disconnected.

深圳市宇捷弘业科技有限公司





电话: 400 186 5117 | 0755-2222 5117 | 137 5117 6688
Q Q: 138235948
微信: 13751176688
邮箱: info@itest.net
网址: www.itest.net
地址: 深圳市龙华区民治优城商务大厦北区A座921



#### **Dimensions** (in mm)



#### Connection

- Normal operation status (Pins 3 and 8) Normal operation means:
  - $\pm 15 V (\pm U_c)$  present
  - 0 V on D-Sub has to be tied
  - zero detector is working
  - compensation current  $\leq I_{PM} DC$
  - green LED indicator switches on.

#### **Mechanical characteristics**

<ul> <li>General tolerance</li> </ul>	±0.5 mm
<ul> <li>Transducer fastening</li> </ul>	
- Horizontal mounting	4 slotted Ø 5.5 mm
and vertical	with 2 slotted holes
	Ø 6.5 mm

Recommended fastening torque 4.4 N·m

Connection of secondary

2 M6 steel screws on D-SUB-9,

UNC 4-40

#### **Remarks**

- $I_{\rm s}$  is positive when  $I_{\rm p}$  flows in the direction of the arrow.
- · We recommend that a shielded output cable and plug are used to ensure the maximum immunity against electrostatic fields.
- Temperature of the primary conductor should not exceed • 100 °C.
- · We recommend to fix the potential of the housing to the ground or 0V (on indicated surfaces).
- Installation of the transducer must be done unless • otherwise specified on the datasheet, according to LEM Transducer Generic Mounting Rules. Please refer to LEM document N°ANE120504 available on our Web site: https://www.lem.com/en/file/3137/download.
- All mounting recommendations are given for a standard • mounting. Screws with flat and spring washers.

#### 深圳市宇捷弘业科技有限公司





电话: 400 186 5117 | 0755-2222 5117 | 137 5117 6688 0 0: 138235948 微信: 13751176688 邮箱: info@itest.net 网址: www.itest.net 地址: 深圳市龙华区民治优城商务大厦北区A座921

- 宇捷弘业公众号
- 宇捷弘业官网
- - 技术及商条服务